



Fender Trim Moldings Installation Instructions

FMS-XJ40-SS, FMS-XJ8-SS, FMS-XJ6-SS, FMS-XJS-SS, FMS-X300-SS

INSTALLATION GUIDE, FOR FENDER TRIM MOLDINGS

- Tools & Accessories necessary:
- 1) Philips head screwdriver
 - 2) Drill
 - 3) Drill bit (size 1/8 inch)
 - 4) Working gloves & protective eye goggles
 - 5) Phillips screws included

INSTALLATION

CAUTION: Please do not remove protective vinyl until Fender Trims are installed.

- Step #1: Determine proper position of fender trim moldings.
- Step #2: Hold in position and make sure Fender Trim is secured tight against wheel well.
- Step #3: Drill hole and mount screws in position.
- Step #4: If Fender Trim has middle hole, start from middle portion and work down to either side.
- Step #5: Remove (blue, white or clear) protective vinyl and view the high polish stainless steel finish of your Fender Trim molding.

Cleaning & Maintenance Instructions

Clean your trims using a soft cloth, water & soap.

CAUTION: Do not use any abrasive material or any kind of polish.

NOTE: For further instruction call your dealer

